


THE SPECIALISTS IN LAND ROVERS • USA

Mounting Instructions for Driving Light Bracket for the Defender Brush Bar

1) To locate light brackets, measure 4 1/2" from the inside of the Brush Bar for the first hole.



- 2) Locate light bracket and mark Brush Bar for holes. Use 1/2" drill for nutserts.
- 3) Install nutserts in Brush Bar holes.
- 4) Mount light bracket

Instructions Questionnaire

We rely on our customers to help us continually improve our instruction sheets. Please FAX or mail any comments, questions, or ideas for improvements you may have.

	1319 Vermont Route 128 Westford, VT 05494								
or Fax:	x: 802-879-9152								
Your Name:Address:				Phone #:Email Adrs:					
Overall,	how would y	you rate the q	uality of this	description of set of instruct	ions? (please	circle one):			
<u>Poor</u> 1 2		<u>Fair</u> 3 4		<u>Good</u> 5 6		Very Good 7 8		Excellent 9 10	
Ideas, C	omments, or	Corrections	(please inclu	de specifics, s	uch as page	number, or st	tep number):		

THANK YOU!

Send To: Rovers North