



THE SOURCE FOR CLASSIC
LAND ROVER PARTS
www.roversnorth.com

Hazard Warning Kit for Series II, IIA & III

COLOR	WIRING
Purple	Live Feed
Black	Earth
Green	Left Hand Indicators
Green/White	Right Hand Indicators
Green/Purple	Follow Instructions below
Green/Yellow	Follow Instructions below

Find the live feed to you existing flasher unit, cut that wire, then connect a Green/Purple to one end of the wire you have cut and Green/Yellow to the other. (The wires from this switch are approximately 500mm long. Depending on the layout of your car you may need to extend some of the wires to reach the connection points listed above). Works on both positive and negative earth vehicles.