



Part Nr. RNA0087

Fits: Defender 110

Suggested Tools:

- 1/4" Socket Wrench
- 10mm Socket
- 10mm Open End Wrench
- Caulking Tool
- 1/4" Drill Bit, Drill



Caulking Tool



Watch the easy installation video on your mobile device.

Defender 110 – Reinforcing Bracket Set – Mud Flap Wing Stay

READ ALL INSTRUCTIONS COMPLETELY BEFORE BEGINNING!

The rear mudflaps on a Defender 110 are bolted between the chassis and the rear body, leaving them hanging off the fragile aluminum skin. Mudflaps take a lot of abuse off-road and frequently tear out of the body mounting.

This simple kit has everything you need to preventatively provide extra support and rigidity on both sides or repair existing body damage while giving the mudflaps a much stronger mount. Once installed, this kit is not visible from the exterior.

Kit includes:

- 2x Mudflap bracket stays
- Sealant to bond the bracket stays to the body
- Stainless steel hardware
- Installation is fast and easy, just unbolt any existing hardware, drill one hole, apply sealant and reassemble.



Below are photos of installing. You can see the rear body was ripped apart where the mudflap had been mounted and the bracket is above that with some glue streaks.



Above: Bracket in place, viewed from inside.



Left: Bracket viewed from below... you can see the torn bit (with the shiny bracket + glue behind it) where mudflap mounts... Originally just hanging off the body skin and easily gets ripped off.



Above: Mudflap bracket hanging off the new support bracket.



Quality control team