



T H E   S P E C I A L I S T S   I N   L A N D   R O V E R S   •   U S A

## Front Receiver Hitch Discovery and Range Rover Classics

1. Remove Air Dam.
2. Support bumper with wood blocks or jack stands.
3. Unbolt bumper. Do not remove bumper.
4. Slide receiver hitch up over bumper brackets and put new bolts through receiver hitch and bumper, tighten in place.
- 5a. For a Discovery, the Air Dam can be put back on as is.
- 5b. For a Range Rover Classic the Air Dam needs a 4x4 hole cut in front of the Air Dam for the receiver hitch end to come through.

**1 800 403-7591**

or (802) 879-0032 • Fax: (802) 879-9152  
email@roversnorth.com • www.roversnorth.com

Rovers North, Inc. • 1319 VT Rt. 128 • Westford, Vermont • 05494-9601 USA



T H E   S P E C I A L I S T S   I N   L A N D   R O V E R S   •   U S A

## Instructions Questionnaire

We rely on our customers to help us continually improve our instruction sheets. Please FAX or mail any comments, questions, or ideas for improvements you may have.

Send To: Rovers North

1319 Vermont Route 128

Westford, VT 05494

or Fax: 802-879-9152

Your Name: \_\_\_\_\_

Phone #: \_\_\_\_\_

Address: \_\_\_\_\_

Email Adrs: \_\_\_\_\_

\_\_\_\_\_

Instruction part number (top right corner) or description of what instructions are: \_\_\_\_\_

Overall, how would you rate the quality of this set of instructions? (please circle one):

Poor		Fair		Good		Very Good		Excellent	
1	2	3	4	5	6	7	8	9	10

Ideas, Comments, or Corrections (please include specifics, such as page number, or step number):

---

---

---

---

---

---

---

---

---

---

**THANK YOU!**

**1 802 879-0032** or (800) 403-7591 • Fax: (802) 879-9152

email@roversnorth.com • www.roversnorth.com

Rovers North, Inc. • 1319 VT Rt. 128 • Westford, Vermont • 05494-9601 USA