



T H E S P E C I A L I S T S I N L A N D R O V E R S • U S A

RNA085 Defender

1. Remove both factory tie down rings located on the bottom of the chassis. Discard the rings.
2. Set the receiver hitch in place. Insert the bolts from the tie down rings to hold the in place, leave bolts loose.
3. Remove the rubber plugs from the front of each chassis horn. Locate the holes on the bottom side of the chassis horns. Install and tighten 2 of the bolts, nuts and washers (supplied) up through the holes. Tighten the tie down bolts.
4. Locate the 2 remaining holes in the receiver hitch and drill 7/16 holes up through the bumper, install bolts, nuts and washers. **Check all hardware for tightness!**



1 802 879-0032

or 1-800-403-7591 • Fax: (802) 879-9152
email@roversnorth.com • www.roversnorth.com

Rovers North, Inc. • 1319 VT Rt. 128 • Westford, Vermont • 05494-9601 USA



T H E S P E C I A L I S T S I N L A N D R O V E R S • U S A

Instructions Questionnaire

We rely on our customers to help us continually improve our instruction sheets. Please FAX or mail any comments, questions, or ideas for improvements you may have.

Send To: Rovers North
1319 Vermont Route 128
Westford, VT 05494

or Fax: 802-879-9152

Your Name: _____
Address: _____

Phone #: _____
Email Adrs: _____

Instruction part number (top right corner) or description of what instructions are: _____
Overall, how would you rate the quality of this set of instructions? (please circle one):

Poor		Fair		Good		Very Good		Excellent	
1	2	3	4	5	6	7	8	9	10

Ideas, Comments, or Corrections (please include specifics, such as page number, or step number):

THANK YOU!

1 802 879-0032 or (800) 403-7591 • Fax: (802) 879-9152
email@roversnorth.com • www.roversnorth.com
Rovers North, Inc. • 1319 VT Rt. 128 • Westford, Vermont • 05494-9601 USA