



THE SOURCE FOR CLASSIC
LAND ROVER PARTS

www.roversnorth.com

Part Nr. RNA086

Fits: Series 109" Station Wagon

Suggested Tools:

- Safety glasses
- 1/2" or 3/8" socket driver
- 5/8" socket / wrench
- 3/8" socket / wrench
- Waxoyl protectant



Class III Receiver Hitch for Series IIA, III Military Chassis



1/2" Bolts, nuts
and washers



Backing plate



3/8" Bolts and
washers



Kit RNA086 shown

Installation

1. Remove the tow plate assembly from the rear frame member if so equipped. For 109" Station Wagons the fuel tank will need to be lowered to gain access to the back of the rear frame member.

Note: Leave all hardware loose until end of project and tighten all at once.

2. Insert the supplied 5/8" bolts through the bottom holes in the face of the receiver hitch and use one washer as a spacer between the receiver hitch and rear frame member. Be sure to include backing plate with bottom bolts.
3. Insert the supplied 3/8" bolts with flat washers through the top holes in the face of the receiver hitch and use two washers as spacers on each bolt between the receiver hitch and rear frame member. Fasten with washers and nuts provided.
4. Insert the two remaining bolts up through the bottom of the rear frame member, using washers as spacers. Tighten all hardware.

Fitting Instructions for Class III Receiver Hitch – Series 109” Station Wagon

