

THE SPECIALISTS IN LAND ROVERS • USA

## Discovery, Series I, and Range Rover Classic Sills

Recommended Fitting Sequence for Discovery Sills:

- 1. Remove plastic sills.
- 2. Place new sill into position and jack up tight into position, ensuring caps are level front and rear.
- 3. Drill through the existing sill holes, creating a hole on the inside of the box section. This allows the bolts provided to pass though the boxed section to be attached to the nuts provided.
- 4. Using compression spacers as shown (steel tube), fit bolts, then fit self tappers to front fender.

## TOOLS/PARTS

Tools:	10mm Drill Bit 13mm Socket 13mm Wrench	
Parts:	Compression Spacers 10 x 100mm Bolts 10mm Nyloc Nuts 10mm Flat Washers No. 8 Self Tappers	16 16 16 32 2



1 800 403-7591

or (802) 879-0032 • Fax: (802) 879-9152



## Instructions Questionnaire

We rely on our customers to help us continually improve our instruction sheets. Please FAX or mail any comments, questions, or ideas for improvements you may have.

	-	1319 Vermont Route 128 Westford, VT 05494										
or Fax:	802-879-9	9152										
					Phone #: Email Adrs:							
Address:					EIIIAII AUIS: _							
	-			description of								
Overali, I	now would	you rate tne q	uanty of this	set of instruct	ons? (piease	circle one):						
Poor		<u> Fair</u>		Good		Very Good		Excellent				
1	2	3	4	5	6	7	8	9	10			
Ideas, Co	omments, or	Corrections	(please inclu	de specifics, s	uch as page i	number, or st	ep number):					

THANK YOU!

Send To: Rovers North