



THE SOURCE FOR CLASSIC  
LAND ROVER PARTS

[www.roversnorth.com](http://www.roversnorth.com)

Part Nr. RNA802

Fits:

Discovery II



### Suggested Tools

- 15mm, 19mm Sockets
- Socket Wrench
- 15mm, 19mm Open Box  
End Wrenches



15mm, 19mm  
Sockets



15mm, 19mm  
Wrenches



Socket  
Wrench

# Fitting Instructions for Discovery II Steering Stabilizer

**READ ALL INSTRUCTIONS COMPLETELY BEFORE BEGINNING!**



**Step 1.** It is best to have the wheels pointing somewhat straight forward to start this project out.



**Step 2.** Locate the stabilizer lower 15mm and 19mm bolts, break tension on the nut and bolt, remove the bolt.



**Fitting Instructions for Brake Shoe Adjuster Kit**

**Step 3.** Remove the bolt on the other end of the steering damper using the same size heads.

**Step 4.** When handling the new steering damper, try to compress it to the correct size to slide into the mounting locations. This will make it easier when under the Land Rover.

**Step 5.** Install passenger side bolt securely to 92lb-ft or 125Nm. Rotate the opposite end to get the correct mounting orientation and do the same to the bottom.

