



T H E S P E C I A L I S T S I N L A N D R O V E R S • U S A

Mud Flap Kit RNK015

- 1) The mud flaps are to be mounted to the underside of the rear cross member immediately behind the rear wheel.
- 2) Position the mud flap assembly on the bottom of the rear cross member so that the outer hole in the bracket is 2 5/8" on center from the outer side edge of the cross member and the bracket is flush with the forward edge of the cross member.
- 3) Mark the remaining hole and drill a 1 1/32" hole and attach with the hardware provided.

NOTE: The tailpipe will have to be removed to drill the center hole.

- 4) Repeat the above steps for the right hand side.



1 802 879-0032 or 1-800-403-7591 • Fax: (802) 879-9152
email@roversnorth.com • www.roversnorth.com

Rovers North, Inc. • 1319 Vermont Route 128 • Westford, Vermont • 05494-9601 USA



T H E S P E C I A L I S T S I N L A N D R O V E R S • U S A

Instructions Questionnaire

We rely on our customers to help us continually improve our instruction sheets. Please FAX or mail any comments, questions, or ideas for improvements you may have.

Send To: Rovers North
1319 Vermont Route 128
Westford, VT 05494

or Fax: 802-879-9152

Your Name: _____
Address: _____

Phone #: _____
Email Adrs: _____

Instruction part number (top right corner) or description of what instructions are: _____
Overall, how would you rate the quality of this set of instructions? (please circle one):

Poor		Fair		Good		Very Good		Excellent	
1	2	3	4	5	6	7	8	9	10

Ideas, Comments, or Corrections (please include specifics, such as page number, or step number):

THANK YOU!

1 802 879-0032 or (800) 403-7591 • Fax: (802) 879-9152
email@roversnorth.com • www.roversnorth.com
Rovers North, Inc. • 1319 VT Rt. 128 • Westford, Vermont • 05494-9601 USA