



THE SPECIALISTS IN LAND ROVERS • USA

Update Discovery I Headlamps

Step 1



The original lights are dull and dated. Time to replace them with a bright and stylish lights. To start, raise the bonnet and secure with prop rod.

Step 2



Locate the large wire ring behind the corner lamp and pull upward. This releases the corner lamp from its mounting for easy removal.

Step 3



Unplug its wire connector by pressing down on the plastic lever and pulling apart.

Step 4



Locate the 3 plastic adjustable fasteners on the back of the headlamp. Rotate their plastic ears to line up with the slotted cut outs in the inner panel.

Step 5



When all 3 are aligned, gently lift out the head lamp. Unplug the wire leads from the back of the headlamp unit. The large contour plug is high and low beam. The small bottom plug is your parking light.

Step 6



Next remove the 3 adjustable fasteners from the back of the headlamp. Take care not to rotate the fastener on the threaded stud as this will change your highlamp alignment. Simply unsnap the threaded stud from the old headlamp and snap it into the new headlamp. .

Step 7



Take care to install them in the same location to avoid changing alignment. Reconnect headlamp wires and fit the headlamp to the inner panel. Then rotate the plastic fasteners to their lock position. This will securely fasten the headlamp.

Step 8



Next fit the corner lamp into position. Plug in its wire lead and pull the large wire ring into position. This will securely fasten the corner lamp.

Step 9



Pop out side lamp using hand pressure. Remove light bulb and replace with new amber bulb.

Step 10



Fit new clear lamp onto bulb holder and press back into the body panel.

Step 11



Test directionals, parking lights, low beam and hi beam lights to ensure all lamp assemblies are functioning correctly. For optimal results have your headlamps professionally aligned. This easily done by any service facility with standard alignment equipment.

1 802 879-0032

or 1-800-403-7591 • Fax: (802) 879-9152
email@roversnorth.com • www.roversnorth.com

Rovers North, Inc. • 1319 VT Rt. 128 • Westford, Vermont • 05494-9601 USA



T H E S P E C I A L I S T S I N L A N D R O V E R S • U S A

Instructions Questionnaire

We rely on our customers to help us continually improve our instruction sheets. Please FAX or mail any comments, questions, or ideas for improvements you may have.

Send To: Rovers North
1319 Vermont Route 128
Westford, VT 05494

or Fax: 802-879-9152

Your Name: _____
Address: _____

Phone #: _____
Email Adrs: _____

Instruction part number (top right corner) or description of what instructions are: _____

Overall, how would you rate the quality of this set of instructions? (please circle one):

Poor		Fair		Good		Very Good		Excellent	
1	2	3	4	5	6	7	8	9	10

Ideas, Comments, or Corrections (please include specifics, such as page number, or step number):

THANK YOU!

1 802 879-0032 or (800) 403-7591 • Fax: (802) 879-9152
email@roversnorth.com • www.roversnorth.com

Rovers North, Inc. • 1319 VT Rt. 128 • Westford, Vermont • 05494-9601 USA