



THE SOURCE FOR CLASSIC
LAND ROVER PARTS

www.roversnorth.com

Part: RNM0004

Fits: Land Rover 90/110,
Defender

Suggested Tools:

- Safety glasses
- Phillips Screwdriver



Phillips
Screwdriver



Safety Glasses

Fitting Procedure for Rovers North Radiator Muff



Installation

RNM0004

1. Start by loosening the grill with a phillips screwdriver on the sides. Fit the bottom corners to radiator grill, making sure that the muff is pulled taut across the grill.
2. Next fit the top left muff corner over the grill corner.
3. Gently roll the right top corner of the muff over the grill corner. **DO NOT FORCE.** Should you experience difficulty readjust the other three corners and start again. Fasten grill back to radiator panel and tighten all screws.

Tip: If the space between the grill and the radiator panel seems insufficient, consider unscrewing and removing the grill entirely to properly fit the radiator muff.

4. To remove - reverse above procedure.



FULL VENTILATION is created by rolling the ventilation flap tightly downward and securing it to the bottom set of snaps on the muff.

PARTIAL VENTILATION is obtained by snapping down the center flap. The top flap snaps are always fastened to the muff and should not dangle free. The second row of flap snaps will attach to the corresponding muff snaps immediately below the location you choose for the top row of flap snaps. The extra flap material created when snapping the ventilation flap down should fold at the bottom tight against the muff.

FULLY CLOSED is created by snapping all the flaps. Use this during extreme winter conditions.

SERVICE HINT: To prevent the stainless steel snaps from freezing together in extreme winter ice conditions, we recommend lightly applying silicone or clear petroleum jelly to snap halves.