

IHE SPECIALISIS IN LAND ROVERS • USA

Fitting Procedure for Rovers North Radiator Muff



- 1. Start by fitting bottom corners to radiator grill, making sure that the muff is pulled taught across the grill.
- 2. Next fit the top left muff corner over the grill corner.
- 3. Now gently roll the right top corner of the muff over the grill corner.
 DO NOT FORCE. Should you experience difficulty readjust the other three corners and start again.
- **4.** To remove reverse above procedure.

PARTIAL VENTILATION is obtained by snapping down the center flap. The top flap snaps are always fastened to the muff and should not dangle free. The second row of flap snaps will attach to the corresponding muff snaps immediately below the location

you choose for the top row of flap snaps. The extra flap material created when snapping the ventilation flap down should fold at the bottom tight against the muff.

FULL VENTILATION is created by rolling the ventilation flap tightly downward and securing it to the bottom set of snaps on the muff.

FULLY CLOSED is created by snapping all the flaps. Use this during extreme winter conditions.

SERVICE HINT: To prevent the stainless steel snaps from freezing together in extreme winter ice conditions, we recommend lightly applying silicone or clear petroleum jelly to snap halves.



1 802 879-0032

Instructions Questionnaire

We rely on our customers to help us continually improve our instruction sheets. Please FAX or mail any comments, questions, or ideas for improvements you may have.

	1319 Vermont Route 128 Westford, VT 05494									
or Fax:	802-879-	802-879-9152								
Your Name:Address:				Phone #:Email Adrs:						
Overall, l	how would	you rate the q	uality of this	description of set of instruct	ions? (please	circle one):				
<u>Poor</u> 1 2		Fair3 4		<u>Good</u> 5 6		Very Good 7 8		Excellent 9 10		
Ideas, Co	omments, or	· Corrections	(please inclu	de specifics, s	uch as page	number, or st	ep number):			

THANK YOU!

Send To: Rovers North