

Instructions for changing Land Rover Hair Pin Series Wired Glow Plugs to Parallel Wired Probe Type Glow Plugs

- a) Remove existing wiring between ballast resistor and glow plugs also between glow plug and earth discard.
- b) Remove existing hair pin type glow plugs from engine and discard.
- c) Fit new probe type glow plugs to engine and tighten to recommended torque.
- d) Using the new wiring supplied, wire the glow plugs and ballast resistor. It is important that the terminal nuts are properly tightened.
- e) Start engine as usual.

