

Work Lamp Kit Instructions For Defender (Rear Mount)

- 1. Remove left rear speaker.
- 2. Remove rear license plate light and mount.
 - a) Drill a 5/16" hole in left hand side of the plastic mount.
 - b) Install the grommet supplied on the work lamp harness.
- 3. Mount the Hella work light to the work light mount bracket.
- 4. Feed the wires from the work light through the grommet in the rear body.
- 5. Reattach license plate light and work light to the rear body of the vehicle.
- 6. Remove drivers seat and gain access to the battery box.
 - a) Locate a suitable spot for the relay and harness.
 - b) Drill a 1/8" 9/64" hole.
 - c) Find the 2 black ground wires with the small eyelets and attach along with the relay into the hole you drilled, using the screw provided.
- 7. Run the length of the wiring harness that has the 2 bullet ends out of the battery box, along the inside of the frame rail, (be careful to stay clear of exhaust pipes and moving parts, i.e. suspension) to left rear wheel well.
 - a) Locate the grommet in the corner and run the work light harness through it.
 - b) You can now connect the main harness to the work light harness with the bullet connectors supplied and reattach your speaker.
- 8. Back in the battery box, run the single yellow wire, marked to auxiliary switch harness, out of the battery box toward the front and up the bulkhead to the grommet for the speedometer cable. Do not feed through the grommet yet.
- 9. Now you must decide where to put the auxiliary light switch. If you have an available plastic hole plug on the underside of the main gauge cluster portion of the dash, continue reading. If not go directly to instruction 10a.
- 10. Remove the 4 screws that hold the main gauge cluster, and move it to the left. Remove the plastic plug and push in the auxiliary light switch in the underside of main cluster panel. (Go to step 11).
 - a) Remove the 3 screws that hold the bottom left hand dash pad and pull it away. Cut out the dash covering for the auxiliary switch. You will see on the backside of this panel there is one or two spots you can do this. Push in the auxiliary light switch.
- 11. In back of the main gauge cluster panel, but not attached to it, you will see a round cylinder shape with 4 or so wires coming out of it. This is the key switch. Locate the white with orange wire, it should be the closest to you. Unplug it and install the grey wire with the 2 way connector onto the key switch. Also reattach the white with orange wire to one side of the 2 way connector. At this time run the single connector to one of the posts on the back of the auxiliary light switch.

LAND

R O

Е

R S

S A

- 12. Now pull the single wire harness through the speedometer grommet and attach it to the second post on the auxiliary light
- 13. Back to the battery box, find the single red wire with the large eyelet on it. This is to be connected to the positive (+) post
- 14. With connections done, turn the key to the accessory position and turn on your light.

SPECIALISTS

switch. Reattach your dash piece(s).

Н Е

on the battery.

Rovers North, Inc. • 1319 VT Rt. 128 • Westford, Vermont • 05494-9601 USA

Instructions Questionnaire

We rely on our customers to help us continually improve our instruction sheets. Please FAX or mail any comments, questions, or ideas for improvements you may have.

	rmont Route 128 l, VT 05494	3						
Eax: 802-87)-9152							
ur Name:dress:			Phone #:Email Adrs:					
-	umber (top right		description of set of instructi					
		·		1	***	0 1	E 11	
Poor 2		·	<u> </u>	od6	Very 0	Good8	Excell 9	ent 10
Poor 2	Fair	4	God 5	6	7	8		
Poor 2	Fair 3	4	God 5	6	7	8		
Poor 2	Fair 3	4	God 5	6	7	8		
Poor 2	Fair 3	4	God 5	6	7	8		

THANK YOU!