

Remote Alarm Setup For '94-'95 Range Rover Classic & '94-'99 Discovery I

New alarm remotes are supplied in pairs. If a new alarm remote is required, it will require initialization to the ECU by using the following procedure:

- 1) Starting conditions: ignition off, doors unlocked, hood switch depressed.
- 2) Carry out instructions 3 through 9 within 8 seconds:
- **3)** Switch ignition ON
- 4) Switch ignition OFF
- 5) Lock doors
- 6) Unlock doors
- 7) Release hood switch
- 8) Switch ignition ON
- 9) Switch ignition OFF

If alarm is correctly accessed, the horn will sound and the LED on the alarm remote will light up. It is now possible to program two remotes of the correct frequency to the vehicle alarm ECU. This must be carried out within two minutes:

10) Press and hold down the button on the first remote until the LED on the dash lights up.

11)Repeat instruction 10 for the second remote.

12) The LED will go out if both remotes have been initialized correctly.

Replacing Alarm Remote Batteries

- 1) Gently pry the remote apart using a coin or a small flat head screwdriver.
- 2) Hold the board in one hand, cup the other hand and clap your hands together to jar the batteries out.

3) Leave the batteries out, operate the remote by pressing the button for 10 seconds to allow the integrated circuit to reset itself.

**CAUTION: HANDLE NEW BATTERIES AS LITTLE AS POSSIBLE. HANDS SHOULD BE CLEAN AND DRY

- **4)** Fit new batteries in clip, positive side up.
- 5) Clip the remote casing back together.





Instructions Questionnaire

We rely on our customers to help us continually improve our instruction sheets. Please FAX or mail any comments, questions, or ideas for improvements you may have.

Send To: Rovers North 1319 Vermont Route 128 Westford, VT 05494

or Fax: 802-879-9152

Phone #: ______ Email Adrs: _____

Poor	Poor Fair		,	Good		Very Good		Excellent	
1	2	3	4	5	6	7	8	9	10

Ideas, Comments, or Corrections (please include specifics, such as page number, or step number):

THANK YOU!

1 802 879-0032 or (800) 403-7591 • Fax: (802) 879-9152 email@roversnorth.com • www.roversnorth.com Rovers North, Inc. • 1319 VT Rt. 128 • Westford, Vermont • 05494-9601 USA